



CROSSOVER CLOSURE USING PRECAST CONCRETE BARRIER

NOTES

1. INSTALL PRECAST CONCRETE BARRIER PER STANDARD DRAWING 612-18.
2. PLACE PRECAST CONCRETE BARRIER FROM EDGE OF PAVEMENT TO EDGE OF PAVEMENT (MINIMUM) EXCLUSIVE OF TERMINALS.
3. USE CRASHWORTHY END TREATMENT IF PRECAST CONCRETE BARRIER CANNOT BE INSTALLED OUTSIDE OF THE CLEAR ZONE.
4. REMOVE CONFLICTING PAVEMENT MARKINGS FROM MAINLINE PER SECTION 203.03 C. DO NOT FOG COAT AREAS WHERE PAVEMENT IS CONCRETE.
5. REMOVE PAVEMENT MARKINGS FROM CROSSOVER PER SECTION 203.03 C.
6. REESTABLISH MAINLINE LONGITUDINAL PAVEMENT MARKING LINES.
7. REESTABLISH RUMBLE STRIPS IF APPLICABLE.
8. DRAWING NOT TO SCALE

REVISIONS				DESIGNED	SCALES SHOWN ARE FOR 11" X 17" PRINTS ONLY CADD FILE NAME CrossoverClosure1.dgn DRAWING DATE: SEPTEMBER 2020	IDAHO TRANSPORTATION DEPARTMENT 	PROJECT NO.	STANDARD DETAIL	English COUNTY KEY NUMBER SHEET OF	NOT APPROVED PRELIMINARY FOR CONSTRUCTION
NO.	DATE	BY	DESCRIPTION	DESIGN CHECKED				MEDIAN CROSSOVER CLOSURE WITH PRECAST CONCRETE BARRIER		
				DETAILED						
				DRAWING CHECKED						