



CROSSOVER CLOSURE USING CABLE BARRIER

NOTES

1. INSTALL CABLE BARRIER PER MANUFACTURER'S SPECIFICATIONS.
2. PLACE CABLE BARRIER FROM EDGE OF PAVEMENT TO EDGE OF PAVEMENT (MINIMUM) EXCLUSIVE OF TERMINALS.
3. REMOVE CONFLICTING PAVEMENT MARKINGS FROM MAINLINE PER SECTION 203.03 C. DO NOT FOG COAT AREAS WHERE PAVEMENT IS CONCRETE.
4. REMOVE PAVEMENT MARKINGS FROM CROSSOVER PER SECTION 203.03 C.
5. REESTABLISH MAINLINE LONGITUDINAL PAVEMENT MARKING LINES.
6. REESTABLISH RUMBLE STRIPS IF APPLICABLE.
7. DRAWING NOT TO SCALE

REVISIONS			
NO.	DATE	BY	DESCRIPTION

DESIGNED
DESIGN CHECKED
DETAILED
DRAWING CHECKED

SCALES SHOWN ARE FOR 11" X 17" PRINTS ONLY

CADD FILE NAME
CrossoverClosure2.DGN

DRAWING DATE:
SEPTEMBER 2020

**IDAHO
TRANSPORTATION
DEPARTMENT**



PROJECT NO.

STANDARD DETAIL
**MEDIAN CROSSOVER
CLOSURE WITH
CABLE BARRIER**

English

COUNTY

KEY NUMBER

SHEET OF

NOT APPROVED
PRELIMINARY
FOR CONSTRUCTION