



3311 State Street  
Boise, Idaho 83707  
Phone: 208-334-8000  
www.itd.idaho.gov

## **ADDENDUM NO. 1**

Date:	June 4, 2018	Owner:	ITD
Project:	Coeur d'Alene Equipment Shed Reroof		
Project No.:	18-100	No. of Pages	3

---

### **NOTICE TO ALL BIDDERS**

You are hereby notified of the following clarifications of and/or revisions to the Drawings and Specifications for the above referenced project.

**THIS ADDENDUM** is hereby made a part of the project requirements and contract documents for referenced project. **BE SURE** to acknowledge it in your Bid Proposal form.

### **ITEM NO.**

1. QUESTION: Is there an anticipated amount of dry rot in the plywood?  
RESPONSE: No....see unit price bid for plywood replacement.
2. QUESTION: Do you want the face sheeted for all buildings?  
RESPONSE: No.
3. QUESTION: OSB or plywood?  
RESPONSE: CDX Plywood
4. QUESTION: 26 gauge steel cannot be Kynar coated as specified (24 gauge is available with Kynar coating)  
RESPONSE: Base bid for 26 GA metal panel to be standard mfg. paint coating. Alternate bid for 24 GA standing seam roof to be Kynar coated.
5. QUESTION:(Detail for Alternate) - Do you want the standing seam panel hemmed and locked into a drip edge or cleat? or do you want it overhung and fastened through the panel?  
RESPONSE: Standing Seam Roof shall be locked in. See attached standing seam drip edge detail.
6. QUESTION: Will ITD pay for building permits.  
RESPONSE: Yes, ITD will pay for building permits. Contractor is responsible for trade permits.
7. QUESTION: How should the bid envelope be addressed?  
RESPONSE: The bid envelope should be addressed to:

IDAHO TRANSPORTATION DEPARTMENT  
3311 STATE STREET  
BOISE, IDAHO 83707  
ATTENTION: TONY PIRC  
BID PROPOSAL: COEUR D'ALENE EQUIP. SHED REROOF



8. ATTACHMENTS:  
Prebid Sign In Sheet  
Standing Seam Drip Edge Detail



# VERTICAL SEAM

## EXTENDED EAVE OVER DECKING

1:12 Slope  
Minimum  
over Solid  
Substrate



**Note:**  
Panel rib must be  
field notched and flat  
part of panel must be  
field bent to accept  
Extended Eave  
(see page 18).

### INSTALLATION NOTES

**All Eave flashings must be installed prior to panel installation.**

1. Position and install Cleat to wall with appropriate fastener, 1'-0" o.c. Make sure Cleat allows for proper Extended Eave attachment.
2. Install Extended Eave flashing by sliding open hem onto Cleat and resting Extended Eave Flashing back against substrate. Fasten to substrate with #10-12 x 1" Pancake Head Woodscrew, 1'-0" o.c.
3. Apply a row of Double Bead of Tape Sealant to extended leg of the Extended Eave flashing.
4. Install panel by engaging field hemmed end of panel (see page 18) to Extended Eave (see pages 20-21 for panel installation).
5. If two or more flashings are required, lap the flashing over the previously installed flashing by a minimum of 2" placing a bead of Tube Sealant between the flashings and securing with pop rivets 2 1/2" o.c.